



KEY NO.	PARTS NAMES	KEY NO.	PARTS NAMES
1	DRAG KNOB	31	BALL BEARING (071404)
2	SIX CORNER	32	PINIOR GEAR BUSHING
3	KEY WASHER (X2)	33	ONE WAY CLUTCH ASSY.
4	DRAG WASHER (X3)	34	PINIOR GEAR
5	EAR WASHER	35	HANDLE SCREW WASHER
6	SPOOL ASSY.	36	HANDLE SCREW
7	CLICK GEAR SPRING	37	BODY
8	CLICK GEAR SPRING	38	ONE WAY CLUTCH SPRING
9	MAIN SHAFT	39	ANTI-REVERSE LEVEL SPRING
10	SIX CORNER SPRING	40	ANTI-REVERSE LEVEL
11	SCREW	41	ANTI-REVERSE BUTTON
12	ROTOR	42	ANTI-REVERSE BUTTON SCREW
13	BAIL ASSY SCREW	43	BALL BEARING (071103)
14	BAIL ARM	44	DRIVE GEAR
15	BAIL ASSY. SCREW (X2)	45	DRIVE GEAR WASHER
16	LINE ROLLER WASHER	46	BALL BEARING (071404)
17	LINE ROLLER	47	BODY COVER
18	BALL BEARING (08052.5X2)	48	BODY COVER SCREW 1 (X3)
19	BAIL ASSY. SCREW	49	HANDLE ASSY.
20	ROTOR COVER SCREW	50	BODY COVER SCREW 2 (X2)
21	ROTOR COVER	51	BODY CAP
22	SPRING HOLDER	52	BODY CAP SCREW
23	YOKE	53	OSCILLATION GEAR
24	BAIL ARM SUPPORT PIN	54	OSCILLATION GEAR SCREW
25	CLICK LEVEL	55	SLIDER
28	SUPPORT PLATE SCREW (X3)	56	SLIDER FIX SCREW
29	PINIOR GEAR WASHER	57	SLIDER COVER
30	BALL BAERING COVER	58	SLIDER COVER SCREW