



| Item | Description          |        | Item | Description        |        |
|------|----------------------|--------|------|--------------------|--------|
| 1    | DRAG KNOB ASSEMBLY   | 刹车调钮   | 32   | BEARING HOLDER     | 单向轴承衬套 |
| 2    | DRAG WASHER RETAINER | 线轮扣环   | 33   | WASHER             | 垫片     |
| 3    | KEY WASHER           | 扁孔垫片   | 34   | SPRING             | 弹簧     |
| 4    | EAR WASHER           | 耳垫片    | 35   | ONE WAY CLUTCH     | 单向组件   |
| 5    | DRAG WASHER          | 羊毛毡    | 36   | PINION GEAR        | 齿杆     |
| 6    | SPOOL                | 线轮     | 37   | MIN COVER          | 主体装饰盖  |
| 7    | SPOOL ASSEMBLY       | 线轮组件   | 38   | WASHER             | 摇臂盖垫片  |
| 8    | SCREW                | 线轮侧片螺丝 | 39   | HANDLE COVER       | 摇臂盖    |
| 9    | ROTOR COVER          | 线轮侧片1  | 40   | BODY               | 主体     |
| 10   | ROTOR                | 线壳     | 41   | SLIDER KEEPER      | 滑块扣片   |
| 11   | SCREW                | 线壳防松螺丝 | 42   | SCREW              | 螺丝     |
| 12   | WASHER               | 方孔垫片   | 43   | REAR COVER         | 后装饰盖   |
| 13   | MAIN SHAFT           | 主轴     | 44   | SCREW              | 后装饰盖螺丝 |
| 14   | ROTOR NUT            | 齿杆螺帽   | 45   | BEARING            | 传动齿轴承  |
| 15   | CLICK GEAR           | 嘀嗒齿轮   | 46   | OSCILLATION GEAR   | 传动齿    |
| 16   | WASHER               | 主轴垫片   | 47   | SLIDER             | 滑块     |
| 17   | SCREW                | 导线轮螺丝  | 48   | SCREW              | 滑块螺丝   |
| 18   | BAIL ARM             | 弯座     | 49   | SCREW              | 主盖螺丝1  |
| 19   | WASHER               | 导线轮垫片  | 50   | MIN COVER          | 主盖装饰盖  |
| 20   | BUSHING              | 导线轮轴衬  | 51   | SCREW              | 主盖螺丝2  |
| 21   | LINE ROLLER          | 导线轮    | 52   | HANDLE             | 摇臂     |
| 22   | BEARING              | 导线轮轴承  | 53   | BODY COVER         | 主盖     |
| 23   | BAIL ASSEMBLY        | 抛线组件   | 54   | BEARING            | 轴承     |
| 24   | SCREW                | 方弯座螺丝  | 55   | WASHER             | 垫片     |
| 25   | ROTOR COVER          | 线轮侧片2  | 56   | DRIVE GEAR         | 主齿盘    |
| 26   | BAIL TRIP SHAFT      | 拨动连杆   | 57   | ANTI-REVERSE LEVER | 反动纽    |
| 27   | SPRING               | 弯座弹簧   | 58   | SCREW              | 反动纽螺丝  |
| 28   | BAIL TRIP LEVER      | 拨动杆    | 59   | SPRING             | 反动扭簧   |
| 29   | SCREW                | 齿杆盖片螺丝 | 60   | ANTI-REVERSE CAM   | 反动杆    |
| 30   | COVER                | 齿杆盖片   | 61   | SPARE SPOOL ASSY   | 备轮组件   |
| 31   | BEARING              | 齿杆轴承   | 62   |                    |        |